



Quick Fixing Guide

Shield™ II - VHB Tape

Aquasign® Shield™ II markers are supplied encased in polycarbonate frames for increased damage tolerance.

- Shield™ II - Clear Polycarbonate Frame
- Shield™ - Black HDPE Frame (Historic Specification)

The installation process remains the same for all Shield™ specifications.



Equipment



Before you begin, remove the tip from the Biohesive® 225 cartridge, cut the nozzle to create a minimum 4mm bead and insert into the application gun

Protective Covers

The protective cover supplied should remain in place throughout the installation process.

Solis® UV-Stable Markers

- Once the installation is complete, Solis® protective covers can be removed at anytime as they do not need protection from sunlight.

Altus™ Fluorescent Markers

- The protective covers on Altus™ markers must be secured with duct tape until the equipment is ready for deployment. This is to prevent the fluorescent pigments fading when exposed to sunlight.

Surface Preparation

- Using the wipes provided, thoroughly clean the equipment surface





Quick Fixing Guide

Shield™ II - VHB Tape

Installation

Step 1: PEEL

- Peel the backing tape from the Shield™ II frame, taking care not to lift the self-adhesive layer

Step 2: STICK

- Place the Aquasign® marker into position
- Once in place, **DO NOT** attempt to reposition, as this will weaken the adhesive bond

Step 3: SEAL

- Apply a **complete** bead of Biohesive® 225 around the frame
- Using a finger, smooth the bead to the marker edges to create a water-tight seal



Additional Information

For more information on the Shield™ II range, visit our Client Portal www.aquasign.com.

[Full Installation Procedure](#) | [Installation Video](#) | [Product Datasheet](#)

[Product Guarantee](#) | [Safety Datasheet](#) | [Full Testing Reports](#)